







Navigation and Function Tips

- | | |
|---|--|
| To:
Open a menu in any application, | Do:
press the  key. |
| Access options and available actions, | press the  key. |
| Close a menu or move back a screen, | press the  key. |
| Return to the Home screen, | press the  key. |
| Show a description on the shortcut bar, | touch and hold the shortcut. |
| Hide the keyboard, | slide your finger down. |

Picture Tips

- | | |
|--|---|
| To:
Take a picture, | Do:
press the Right Convenience key. |
| Lock the focus on a subject before you take a picture, | press the Right Convenience key halfway. |

Music Tips

- | | |
|--------------------------------------|--|
| To:
Pause a song or video, | Do:
press the  key. |
| Resume playing a song or video, | press the  key again. |

For more actions, see the setup wizard on your BlackBerry® smartphone.

For more information, please visit www.blackberry.com/storm  **BlackBerry Storm.**

©2008 Research In Motion Limited. All Rights Reserved. BlackBerry®, RIM®, Research In Motion®, SureType® and related trademarks, names and logos are the property of Research In Motion Limited and are registered and/or used in the U.S. and countries around the world. MKT-22354-001



BlackBerry Storm smartphone

Tips

www.blackberry.com/storm/tips



 **BlackBerry Storm.**



BlackBerry® Storm™ smartphone

Tips



Lock key

Lock the device
Turn on standby mode

Mute key

Play/pause a media file
Mute a call

Left Convenience key

Open the voice dialing application

Headset Jack

Volume keys

MicroUSB port

Right Convenience key

Open the camera
Autofocus
Take a picture

Menu key

Open the menu in an application

Escape key

Move back a screen
Close a menu

Send key

Open the phone
Call a highlighted phone number

End/Power key

Return to the Home screen
End a call
Turn on/off your device

Getting Started

To set up the BlackBerry® Storm™ smartphone, complete the following tasks. You can also see the Getting Started Guide (comes with the smartphone) or click Help on the device for step-by-step instructions.

- Insert the SIM card.
- Insert the battery.
- Charge the battery.
- Complete the setup wizard.

Touchscreen Tips

To:

Select an item,

Do:

click (press) the item.

Highlight an item or place the cursor,

touch the screen lightly.

Scroll down,

touch and hold near the bottom of the screen.

Scroll up,

touch and hold near the top of the screen.

Move down a screen,

slide your finger up quickly.

Move up a screen,

slide your finger down quickly.

Move to the next item,

slide your finger to the left quickly.

Move to the previous item,

slide your finger to the right quickly.

Go to <http://www.syncmyemail.com> for more tips.